




**CONTRACTOR  
SOURCE**

Save where  
the pros do

# CABINET ASSEMBLY

### Hardware List


NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	9	
3	SHELF CLIP	4	
4	BALL-BEARING SIDE MOUNT SLIDE	2	
5	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	4	
6	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	10	
7	BUMPER	6/8/12	
8	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	50	
9	1 1/4" SOFTCLOSE HINGE	2/4	



### Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP & BOTTOM PANEL	1
D	TOE KICK	1
E	FACE FRAME	1
F	DRAWER BOX BACK	4
G	DRAWER BOX SIDE	4
H	DRAWER BOX BOTTOM	2
I	ADJUSTABLE SHELF	1
J	DRAWER HEAD	1/2
K	CABINET DOOR	1/2

## 01 | CABINET ASSEMBLY : BASE




Getting started:


Prepare a protection layer, a screwdriver

- ❑ **STEP 1:**  
Joint side panel with back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- ❑ **STEP 2:**  
Joint bottom panel with side panel
- ❑ **STEP 3:**  
Joint the another side panel with bottom & back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- ❑ **STEP 4:**  
Attach frame on and toekick board using 6 (NO.1) metal clips and 30 (NO.8) 1/2" flat head screw
- ❑ **STEP 5:**  
Joint the drawer together, then install the drawer guide using 8 (NO.8) 1/2" flat head screw and 2 (No.5) 3/4" round head screw for each drawer
- ❑ **STEP 6:**  
Put on the adjustable shelf
- ❑ **STEP 7:**  
Fix drawer head on the drawer box side and fix door onto the frame, each door using 2 (No.9) 1 1/4" hinge 2 (No.5) 3/4" round head screw on frame and 4 (No.6) 5/8" flat head screw on door ; last adjust overlay


STEP 1




STEP 2





STEP 3




STEP 4




STEP 5 / DRAWER BOX



STEP 6



STEP 7




Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

**02 | CABINET ASSEMBLY : BLIND BASE**

Hardware List


NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	7	
3	SHELF CLIP	4	
4	BALL-BEARING SIDE MOUNT SLIDE	1	
5	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	2	
6	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	6	
7	BUMPER	6	
8	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	50	
9	1 1/4" SOFTCLOSE HINGE	2	



Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP & BOTTOM PANEL	1
D	TOE KICK	1
E	FACE FRAME	1
F	DRAWER BOX BACK	2
G	DRAWER BOX SIDE	2
H	DRAWER BOX BOTTOM	1
I	ADJUSTABLE SHELF	1
J	DRAWER HEAD	1
K	CABINET DOOR	1

## 02 | CABINET ASSEMBLY : BLIND BASE




Getting started:


Prepare a protection layer, a screwdriver

- ❑ **STEP 1:**  
Joint side panel with back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- ❑ **STEP 2:**  
Joint bottom panel with side panel
- ❑ **STEP 3:**  
Joint the another side panel with bottom & back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- ❑ **STEP 4:**  
Attach frame on and toekick board using 6 (NO.1) metal clips and 30 (NO.8) 1/2" flat head screw
- ❑ **STEP 5:**  
Joint the drawer together, then install the drawer guide using 8 (NO.8) 1/2" flat head screw and 2 (No.5) 3/4" round head screw for each drawer
- ❑ **STEP 6:**  
Put on the adjustable shelf
- ❑ **STEP 7:**  
Fix drawer head on the drawer box side and fix door onto the frame, using 2 (No.9) 1 1/4" hinge 2 (No.5) 3/4" round head screw on frame and 4 (No.6) 5/8" flat head screw on door, last adjust the overlay


STEP 1




STEP 2





STEP 3




STEP 4




STEP 5 / DRAWER BOX



STEP 6











STEP 7



Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

Hardware List


NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	14	
2	SHELF CLIP	16	
3	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	2	
4	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	4	
5	BUMPER	2	
6	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	56	
7	1 1/4" SOFTCLOSE HINGE	2	



Parts List

NO	DESCRIPTION	QTY
A	FRONT SIDE PANEL	2
B	BACK SIDE PANEL	2
C	TOP&BOTTOM PANEL	2
D	BACK PANEL	1
E	FACE FRAME	1
I	ADJUSTABLE SHELF	2
K	CABINETS DOOR	1







## 03 | CABINET ASSEMBLY : DCW



Getting started:

Prepare a protection layer, a screwdriver








- STEP 1:**  
Join the front side panel with the back side panel using 2 (NO.1) metal clips and 8 (NO.6) 1/2" flat head screw
- STEP 2:**  
Join the bottom and top panel with the front side panel and back side panel using 4 (NO.1) metal clips and 16 (NO.6) 1/2" flat head screw
- STEP 3:**  
Join the back panel with the the bottom and top panel
- STEP 4:**  
Join the another back side panel and front side panel with bottom & back panel using 4 (NO.1) metal clips and 16 (NO.6) 1/2" flat head screw
- STEP 5:**  
Attach the face frame using (NO.1) metal clip to fix on top/ bottom panel, then put on the adjustable shelf
- STEP 6:**  
Fix door onto the frame using 2 (No.8) 1 1/4" hinge 2 (No.3) 3/4" round head screw on frame and 4 (NO.4) 5/8" flat head screw on door the last adjust the overlay




Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

## 04 | CABINET ASSEMBLY : DRAWER BASE

### Hardware List

NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	14	
3	BALL-BEARING SIDE MOUNT SLIDE	3	
4	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	6	
5	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	6	
6	BUMPER	12	
7	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	50	




### Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP&BOTTOM PANEL	1
D	TOE KICK	1
E	FACE FRAME	1
F	DRAWER BOX BACK	6
G	DRAWER BOX SIDE	6
H	DRAWER BOX BOTTOM	3
J	DRAWER HEAD	3



## 04 | CABINET ASSEMBLY : DRAWER BASE




Getting started:


Prepare a protection layer, a screwdriver

- STEP 1:**  
Joint side panel with back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- STEP 2:**  
Joint bottom panel with side panel
- STEP 3:**  
Joint the another side panel with bottom & back panel using 2 (NO.1) metal clips and 10 (NO.8) 1/2" flat head screw
- STEP 4:**  
Attach frame on and toekick board using 6 (NO.2) metal clips and 30 (NO.8) 1/2" flat head screw
- STEP 5:**  
Joint the drawer together, then install the drawer guide using 8 (NO.8) 1/2" flat head screw and 2 (No.5) 3/4" round head screw for each drawer
- STEP 6:**  
Fix drawer head on the drawer box side then adjust overlay



STEP 1




STEP 2




STEP 3 / DRAWER BOX




STEP 4



STEP 5





STEP 6




Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

**05 | CABINET ASSEMBLY : LAZY SUSAN**

Hardware List


NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	32	
3	3/4" ROUND HEAD SCREW(HINGE ON FACE FRAME)	2	
4	5/8" FLAT HEAD SCREW(HINGE ON DOOR)	24	
5	BUMPER	4	
6	1/2" FLAT HEAD SCREW(FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	40	
7	165 DURO SOFT CLOSE HINGE	2	
8	WOOD BLOCK	4	



Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	BOTTOM PANEL WITH BASKET	1
C	TOE KICK	2
D	FACE FRAME	2
E	FRONT SIDE PANEL	2
F	BACK SIDE PANEL	2
H	CABINETS DOOR	2
I	CENTRAL SHELF WITH BASKET	1
J	REINFORCING PANEL	1

## 05 | CABINET ASSEMBLY : LAZY SUSAN




Getting started:

Prepare a protection layer, a screwdriver


- STEP 1:**  
Join the front side panel with back side panel using 2 (NO.1) metal clips and 8 (NO.6) 1/2" flat head screw
- STEP 2:**  
Join the bottom panel and central shelf (with basket) with the front side panel and back side panel
- STEP 3:**  
Join the back panel with the back side panel using 3 (NO.2) 1" flat head screw
- STEP 4:**  
Join the another back side panel with the back panel as step 3 then Join the front side panel with back side panel using 2 (NO.1) metal clips and 10 (NO.6) 1/2" flat head screw
- STEP 5:**  
Attach frame on and toekick board using 6 (NO.1) metal clips and 24 (NO.6) 1/2" flat head screw and the contact area of the two toe kicks need 2 (NO.2) 1" flat head screw to fix
- STEP 6:**  
Attach the wood block (NO.8) on the top corner using 6 (NO.2) 1" flat head screw and fix the reinforcing panel using 4 (NO.2) 1" flat head screw
- STEP 7:**  
Fix door onto the frame; using 2 (NO.3) 3/4" round head screw on frame and 4 (NO.4) 5/8" flat head screw on door, adjust the overlay

Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



### Hardware List

NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	14	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	6	
3	SHELF CLIP	16	
4	3/4" ROUND HEAD SCREW(HINGE ON FACE FRAME)	5	
5	5/8" FLAT HEAD SCREW(HINGE ON DOOR)	10	
6	BUMPER	4	
7	1/2" FLAT HEAD SCREW(FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	56	
8	1 1/4" SOFTCLOSE HINGE	5	



### Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP&BOTTOM& FIXED SHELF	3
D	TOE KICK	1
E	FACE FRAME	1
I	ADJUSTABLE SHELF	5
K	CABINETS DOOR	4

## 06 | CABINET ASSEMBLY : PANTRY




Getting started:


Prepare a protection layer, a screwdriver

- STEP 1:**  
Joint side panel with back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 2:**  
Joint bottom and top panel and fixed middle shelf with side panel
- STEP 3:**  
Joint another side panel with top, bottom & back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 4:**  
Attach frame on and toekick board using 6 (NO.1) metal clips and 30 (NO.7) 1/2" flat head screw
- STEP 5:**  
Put on the adjustable shelf
- STEP 6:**  
Fix door onto the frame using (No.8) 1 1/4" hinge (No.4) 3/4" round head screw on frame and 4(No.5) 5/8" flat head screw on door, last adjust overlay


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5










STEP 6



Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

**07 | CABINET ASSEMBLY : SINK BASE**

Hardware List

NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	11	
4	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	4	
5	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	8	
6	BUMPER	4	
7	1/2" FLAT HEAD SCREW(FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	40	
8	1 1/4" SOFTCLOSE HINGE	4	



Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP&BOTTOM PANEL	1
D	TOE KICK	1
E	FACE FRAME	1
J	DRAWER HEAD	2
K	CABINETS DOOR	2

## 07 | CABINET ASSEMBLY : SINK BASE




Getting started:


Prepare a protection layer, a screwdriver

- STEP 1:**  
Joint side panel with back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 2:**  
Joint bottom panel with side panel
- STEP 3:**  
Joint the another side panel with bottom & back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 4:**  
Attach frame on and toekick board using 6 (NO.1) metal clips and 30 (NO.7) 1/2" flat head screw
- STEP 5:**  
Fix drawer head on the frame using 4 (NO .2) 1" flat head screw for each drawer head
- STEP 6:**  
Fix door onto the frame, each door using 2 (No.8) 1 1/4" hinge 2 (No.4) 3/4"round head screw on frame and 4 (No.5) 5/8" flat head screw on door, then adjust overlay


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5




STEP 6



Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

Hardware List

NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	4	
3	SHELF CLIP	8	
4	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	2	
5	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	4	
6	BUMPER	2	
7	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	40	
8	1 1/4" SOFTCLOSE HINGE	2	




Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP&BOTTOM PANEL	2
E	FACE FRAME	1
I	ADJUSTABLE SHELF	2
K	CABINETS DOOR	1



## 08 | CABINET ASSEMBLY : WALL BLIND



Getting started:

Prepare a protection layer, a screwdriver

**STEP 1:**

Joint side panel with back panel

**STEP 2:**

Joint bottom and top panel with side panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw

**STEP 3:**

Joint the another side panel with top/bottom & back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw

**STEP 4:**

Attach frame on using 4 (NO.1) metal clips and 20 (NO.7) 1/2" flat head screw


**STEP 5:**

Put on the adjustable shelf


**STEP 6:**

Fix door onto the frame; each door using 2 (No.8) 1 1/4" hinge 2 (No.4) 3/4" round head screw on frame and 4 (No.5) 5/8" flat head screw on door; adjust overlay


### STEP 1




### STEP 2




### STEP 3




### STEP 4



### STEP 5




### STEP 6



Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips

Hardware List


NO.	DESCRIPTION	QTY	PICTURE
1	METAL CLIP	10	
2	1" FLAT HEAD SCREW FOR DF AND FRONTDRAWER BOX	6	
3	SHELF CLIP	8	
4	3/4" ROUND HEAD SCREW (HINGE ON FACE FRAME)	4	
5	5/8" FLAT HEAD SCREW (HINGE ON DOOR)	8	
6	BUMPER	4	
7	1/2" FLAT HEAD SCREW (FOR METAL CLIP AND REAR BRACKET OF DRAWER SLIDE)	40	
8	1 1/4" SOFTCLOSE HINGE	4	



Parts List

NO	DESCRIPTION	QTY
A	BACK PANEL	1
B	SIDE PANEL	2
C	TOP & BOTTOM PANEL	2
E	FACE FRAME	1
I	ADJUSTABLE SHELF	2
K	CABINETS DOOR	2

## 09 | CABINET ASSEMBLY : WALL




Getting started:


Prepare a protection layer, a screwdriver

- STEP 1:**  
Joint side panel with back panel
- STEP 2:**  
Joint bottom and top panel with side panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 3:**  
Joint the another side panel with bottom & back panel using 2 (NO.1) metal clips and 10 (NO.7) 1/2" flat head screw
- STEP 4:**  
Attach frame on using 4 (NO.1) metal clips and 20 (NO.7) 1/2" flat head screw
- STEP 5:**  
Put on the adjustable shelf
- STEP 6:**  
Fix door onto the frame, each door using 2 (No.8) 1 1/4" hinge 2 (No.4) 3/4" round head screw on frame and 4 (No.5) 5/8" flat head screw on door, last adjust the overlay


STEP 1




STEP 2




STEP 3




STEP 4



STEP 5



STEP 6



Please visit [www.hdicabinetry.com](http://www.hdicabinetry.com) for alternate assembly instructions, eliminating the need for metal clips